

## Intergrain Enviropo Invisible Floor Finish

AU\_DW02768

<b>Part A</b>	701W0351
---------------	----------

### Description

Enviropo Invisible Floor Finish is a hard-wearing clear finish designed for most timber flooring and other interior timber. This new-generation technology gives an invisible sheen finish that has the appearance of bare wood and provides the feel of natural timber. Enviropo Invisible Floor Finish removes the glossy appearance from existing timber floors with one coat<sup>^</sup> and no sanding, helping transform and modernise whilst providing excellent water, stain and abrasion resistance. A quick drying time (recoat in 4 hours) and low odour make Enviropo Invisible Floor Finish a great choice for residential projects.

### Features

- Invisible sheen
- No sealer required
- No sanding required when applying over existing coating\*

### Uses

Interior timber flooring and other interior timber




### Precautions And Limitations

Do not apply if air or substrate temperatures are above 35°C or below 10°C.

\*Ensure existing coating remains in sound condition. If coating is not in sound condition, it will need to be sanded back.

### Performance Guide

<b>Weather</b>	Interior use only	<b>Heat Resistance</b>	Up to 100C.
<b>Water</b>	Good for splashes and spillage.	<b>Abrasion</b>	Very good.

Typical Properties																											
<b>Gloss Level</b>	<5% at both 60 degrees and 85 degrees	<b>Colour</b>	Clear																								
<b>Number Of Coats</b>	1-3	<b>V.O.C. Level</b>	<50g/L																								
<b>Meets GBCA VOC Requirement?</b>	Yes. Total Volatile Organic Content (TVOC) values are calculated in accordance to the stated methodology within Green Star Technical Manuals. The TVOC content is theoretically calculated as the sum total of the known VOC values of the product's raw material components. These materials include the base paint plus additional low VOC tinter required for non-factory packaged colours.	<b>Touch Dry</b>	2 hours																								
<b>Clean Up</b>	 Water																										
<b>Application Method</b>	  Brush      Roller																										
<b>Application Conditions</b>	<table border="0" style="width: 100%;"> <tr> <td style="text-align: center;"><b>Solids By Volume</b></td> <td style="text-align: center;">27</td> <td></td> <td></td> </tr> <tr> <td></td> <td style="text-align: center;"><b>Min</b></td> <td style="text-align: center;"><b>Max</b></td> <td style="text-align: center;"><b>Recommended</b></td> </tr> <tr> <td><b>Wet Film Per Coat (microns)</b></td> <td></td> <td></td> <td></td> </tr> <tr> <td><b>Dry Film Per Coat (microns)</b></td> <td></td> <td></td> <td></td> </tr> <tr> <td><b>Recoat Time (min)</b></td> <td></td> <td></td> <td></td> </tr> <tr> <td><b>Theoretical Spread Rate (m<sup>2</sup>/L)</b></td> <td></td> <td style="text-align: center;">10</td> <td></td> </tr> </table>			<b>Solids By Volume</b>	27				<b>Min</b>	<b>Max</b>	<b>Recommended</b>	<b>Wet Film Per Coat (microns)</b>				<b>Dry Film Per Coat (microns)</b>				<b>Recoat Time (min)</b>				<b>Theoretical Spread Rate (m<sup>2</sup>/L)</b>		10	
<b>Solids By Volume</b>	27																										
	<b>Min</b>	<b>Max</b>	<b>Recommended</b>																								
<b>Wet Film Per Coat (microns)</b>																											
<b>Dry Film Per Coat (microns)</b>																											
<b>Recoat Time (min)</b>																											
<b>Theoretical Spread Rate (m<sup>2</sup>/L)</b>		10																									
<b>Typical Properties Notes</b>	<p>COVERAGE 8–10m<sup>2</sup>/L depending on the porosity of the timber.</p> <p>DRY TIMES Touch Dry: 2 hours. Recoat: Allow a minimum of 4 hours drying between coats. Floors will take light foot traffic after 12 hours, and normal foot traffic after 3 days. Replace furniture after 7 days. Dry times are based on drying conditions of 25°C and 50% relative humidity. DRYING TIMES WILL BE LONGER IN CONDITIONS COOLER THAN 25°C OR MORE HUMID THAN 50% HUMIDITY</p>																										

Application Guide	
<b>Surface Preparation</b>	<ul style="list-style-type: none"> <li>All surfaces must be clean, dry, free of wax, grease, dust and other contaminants. The presence of contaminants increases the possibility of rejection and delamination.</li> </ul> <p><b>NEW TIMBER</b> Prepare cork in accordance with cork manufacturer's instructions. All nail holes and cracks should be filled with Intergrain Woodblend putty. Do not use linseed oil putty. Ensure floor is even; sand to a flat even surface if required. Final sand should be with 150 mesh screenback, and vacuum thoroughly with a commercial grade vacuum cleaner to remove all sanding dust.</p> <p><b>PREVIOUSLY FINISHED SURFACES</b> Including Floating Floors. Wash the floor with Enviropro Squeaky Clean as per the label instructions. If patches of the previous coating have worn back to expose bare timber, then for the most even finish, we recommend that the full floor be sanded back to bare timber, and product applied as per 'new timber' directions.</p>
<b>Application Procedure And Equipment</b>	<ul style="list-style-type: none"> <li><b>MIXING</b> Shake Invisible Floor Finish for at least 1 minute to ensure any settled matting agent is reincorporated. Strain product before use.</li> </ul> <p>It is recommended to shield doorways, fireplaces and windows from dust, dirt or other contaminants settling on the surface between coats, as this will affect the finished appearance. Do not completely seal, as adequate ventilation is required to assist with drying. Do not apply if air or substrate temperatures are above 35°C or below 10°C. If using in temperatures above 30°C, Enviropro Wet Edge Extender can be added to Invisible Floor Finish to a maximum of 5% to ease application, follow instructions on the Wet Edge Extender label. If using more than one pack of Invisible Floor Finish, it is recommended to mix all packs together to achieve product uniformity before use. For added durability and stain resistance, add 1 part Enviropro Endure 2 Pack Part B to 9 parts Invisible Floor Finish.</p> <p><b>NEW TIMBER</b> Apply 2 coats of Invisible Floor Finish. Cut in edges using a brush along the grain, then apply to the rest of the surface using a 10mm nap microfibre roller. Finishing strokes should be in the direction of the grain. If required, lightly sand between coats to remove any grain raise. To increase the wear resistance, apply 3 coats of Invisible Floor Finish. On porous timbers, apply 3 coats of Invisible Floor Finish to ensure a uniform finish.</p> <p><b>PREVIOUSLY FINISHED SURFACES</b> Including Floating Floors. To ensure adhesion, a test patch is recommended after the surface has been prepared. Apply a small test area with one coat of Invisible Floor Finish, allow to dry for 24 hours then firmly press a strip of sticky tape over the coating and rip off quickly. If the coating is removed, sand the full surface back to bare timber. If the coating is not removed, apply 1–2 coats of Invisible Floor Finish using a 10mm nap microfibre roller and brush edges as per new floor application. Apply 2 coats for optimal durability and stain resistance.</p> <p><b>SLIP RESISTANCE</b> Tested to AS 4586:2013 Slip resistance classification of new pedestrian surface materials.</p> <p>When applied according to the instructions detailed above, Invisible Floor Finish achieves a wet slip resistance rating of P3.</p> <p>For a higher slip resistance, Intergrain UltraGrip can be added to Invisible Floor Finish. When 5% of Intergrain UltraGrip is added to each coat of Invisible Floor Finish, the coating system will achieve a wet slip resistance rating of P4.</p> <p>When UltraGrip is added, the sheen or gloss level of the resultant coating will be lower than normal. When using UltraGrip, do not sand between coats. When using UltraGrip with Invisible Floor Finish, decant Invisible Floor Finish into another clean container before adding the UltraGrip. While stirring, add UltraGrip slowly to avoid generating dust. Stir in UltraGrip thoroughly with a flat blade stirrer or drill mixer until fully mixed in and lump-free. Stir regularly during use.</p>

Health And Safety			
<b>MSDS Number</b>	DLXGHCEN003459	<b>Using Safety Precautions</b>	Avoid contact with skin and eyes. Avoid breathing dust, fume, gas, mist, vapour or spray. Wear overalls, safety shoes, impervious gloves and safety glasses. Use only in well ventilated areas. Wash hands after use. Keep containers closed when not in use.
<b>Health Effects</b>	<p>FIRST AID: If poisoning occurs, contact a Doctor or Poisons Information Centre (Phone Australia 131 126; New Zealand 0800 764 766). If medical advice is needed, have product container or label at hand.</p> <p>SWALLOWED: If swallowed, do NOT induce vomiting. Give a glass of water. Seek medical advice.</p> <p>EYE: If in eyes, hold eyes open, flood with water for at least 15 minutes and see a doctor.</p> <p>SKIN: If skin contact occurs, remove contaminated clothing and wash skin thoroughly. If irritation occurs seek medical advice.</p> <p>INHALED: Remove from contaminated area. Seek medical advice.</p>	<b>Flammability</b>	Non-flammable
<b>Fire Suppression</b>	If material is involved in a fire use water fog (or if unavailable fine water spray), alcohol resistant foam, standard foam, dry agent (carbon dioxide, dry chemical powder).	<b>Protective Equipment</b>	Wear overalls, safety shoes, impervious gloves and safety glasses
<b>Storage</b>	Keep containers closed when not in use.	<b>Disposal</b>	Do not pour leftover paint down the drain. Unwanted paint should be brushed out on newspaper, allowed to dry and then disposed of via domestic waste collections. Empty paint containers should be left open in a well ventilated area to dry out. When dry, recycle the container via steel can recycling programs. Disposal of empty paint containers via domestic recycling programs may differ between local authorities. Check with your local council first.
<b>Other</b>	Emergency Tel: Australia – 1800 033 111 New Zealand – 0800 734 607		
<b>In the case of emergency, please call 1800 033 111</b>			

Transport And Storage	
<b>Pack A</b>	701W0351
<b>Size</b> 5L	<b>Weight</b> 5.37kg

**Disclaimer**

Dulux, Selleys and Other marks followed by ® are registered trademarks. Marks followed by the symbol of ™ are trademarks.

The data provided within the Duspec system is correct at the time of publication, however it is the responsibility of those using this information to check that it is current prior to specifying or using any of these coating/product systems.

DISCLAIMER: Any advice, recommendation, information, assistance or service provided by any of the divisions of DuluxGroup (Australia) Pty Ltd or its related entities (collectively, DuluxGroup) in relation to goods manufactured by it or their use and application is given in good faith and is believed by DuluxGroup to be appropriate and reliable. However, any advice, recommendation, information, assistance or service provided by DuluxGroup is provided without liability or responsibility PROVIDED THAT the foregoing shall not exclude, limit, restrict or modify the right entitlements and remedies conferred upon any person or the liabilities imposed upon DuluxGroup by any condition or warranty implied by Commonwealth, State or Territory Act or ordinance void or prohibiting such exclusion limitation or modification. Coating/product systems can be expected to perform as indicated on the Duspec Spec Sheet so long as applications and application procedures of the individual products are followed as recommended on the appropriate Product data Sheet. "DuluxGroup" "Dulux" "Selleys" "Berger" "Berger Gold Label" "Hadrian" "Walpamur" "Levene" "Acratex" and Other marks followed by ® are registered trademarks of DuluxGroup (Australia) Pty Ltd ABN 67 000 049 427. Marks followed by the symbol ™ are trademarks.

Please note that this document is only valid for 60 days from the date of issue.

DuluxGroup (Australia) Pty Ltd 1956 Dandenong Road, Clayton, Victoria 3168 AU ABN 67 000 049 427