

Feast Watson Matt Look Deck on New Timber [Exterior]

AU_SW14732

Description
FEAST WATSON MATT LOOK DECK IS A WATER BASED MODIFIED OIL THAT PROVIDES A LOWER SHEEN LOOK AND LONG LASTING PROTECTION TO DECKING, FENCES, STEPS AND ALL EXTERIOR TIMBER. THE UNIQUE FORMULA OF MATT LOOK DECK PENETRATES TIMBER MORE EFFECTIVELY THAN STANDARD ACRYLIC WATER BASED TIMBER COATINGS. IT GIVES A DURABLE LOWER SHEEN FINISH WITH EXCELLENT DIRT RESISTANCE – WHICH MEANS IT'S EASIER TO CLEAN AND KEEP YOUR DECK LOOKING GOOD BETWEEN COATS.

Summary
Lower sheen, natural look Hybrid Technology™ Fast dry, water wash up

Substrate And Substrate Preparation	
Substrate Notes:	<p>SUBSTRATE DESCRIPTION</p> <p>NEW TIMBER New timber items should be delivered in a clean dry condition, just prior to installation. The timber should be inspected for physical defects, such as splinters, cracks, woolly grain, machine marks, and knot holes and also for other defects such as sap and tannin stains, and resin exudation from knots. Examine surfaces for wax or preservatives. Moisture content should be close to equilibrium, usually 10-17% for satisfactory staining or coating. Timber should be stored out of the weather before painting. Timber left exposed to the weather for as little as one month prior to painting will suffer from reduced paint adhesion and durability.</p> <p>AGED TIMBER Old timber surfaces should be inspected for dry rot, mould or fungus, excessive water content, grey and weathered timber, grain cracking, resins, stains, old unsound paint, dirt and any surface contamination. These defects should be rectified prior to painting.</p> <p>TANNIN RICH TIMBER Tannins are water-soluble compounds present in some timbers such as meranti, merbau, kwila, western red cedar and tallowwood. These tannins are leached out by water or moisture and can cause staining of surrounding areas. They are seen as dark coloured stains either under or within a coating. Tannin staining is most obvious in light coloured coatings, such as whites. Darker and wood-toned colours hide the tannin stains best. When using light colours on tannin rich timbers, an appropriate primer should be used to seal the tannins in the wood.</p> <p>MANUFACTURED HARDBOARD These products are manufactured as smooth sheets consisting of wood fibres bound with either natural lignin or a small percentage of phenolic resin. Hardboard is widely used as interior panelling but is vulnerable to moisture and therefore not suitable for exterior exposure or in high condensation conditions. Repairing damaged hardboard is not generally practical and it is advisable to completely replace any damaged sections. These products are manufactured from timber fibre bound with thermosetting phenol formaldehyde resin. They contain wax which may inhibit the drying of solvent based alkyd enamels and tannins which may bleed through water based coatings. As manufactured the smooth surfaces provide an ideal surface for finishing but machined edges are more porous and may show fibre raising when primed.</p>
Substrate Preparation Notes:	<p>ASSESS SUITABILITY Ensure the wood is thoroughly clean and dry before commencing. If there is any doubt, measure moisture content which must be between 10-17% before staining or finishing can commence.</p> <p>REMOVE SURFACE CONTAMINANTS Examine the surface for the presence of sap, grease, oil, wax, tannin, building marks, or other contaminants. Scrape off and remove residual contaminants by solvent cleaning. Use scraper to remove dirt and mortar splashes. Any greyed wood fibres on aged timbers need to be removed by sanding and / or suitable chemical wood cleaner. CLEAN Clean to remove all dirt, dust and all other surface contaminants by using a suitable cleaning agent and rinse off with clean water. Treat mould with a suitable mould treatment.</p> <p>REPAIR SURFACE IMPERFECTIONS Fill nail holes, cracks and other defects with a suitable wood filler and allow to dry thoroughly.</p> <p>SANDING Sand dressed timber with fine sandpaper in direction of the grain and along the full length of the board. Round off all sharp edges to a minimum of 2 mm radius in order to achieve an even film build and uniform paint coverage.</p>

Coating System Summary	
Prep Coat:	AUDW0751: Feast Watson Woodclean
1st Coat:	AU_DW02187: Feast Watson Matt Look Deck
2nd Coat:	AU_DW02187: Feast Watson Matt Look Deck
Optional:	AU_DW02187: Feast Watson Matt Look Deck
Please refer to the coating system details below	

Coating System			
Coat Type:	Prep Coat	Datasheet:	AUDW0751 Feast Watson Woodclean
Application Methods:	  Brush Other Stiff bristle brrom or brush		
Coating Application Details:	<p>Dilute WOODCLEAN in water by mixing one (1) part WOODCLEAN to four (4) parts water. Stir diluted mixture thoroughly.</p> <p>Apply WOODCLEAN by scrubbing into timber surface with a stiff bristle brush.</p> <p>Leave formula for approximately 20 minutes to penetrate the timber surface. Do not allow surface to dry. Prevent drying by wetting timber with a very light mist spray.</p> <p>After 20 minutes rinse thoroughly with a high-pressure water cleaner.</p> <p>For more stubborn or badly weathered areas, use a higher concentration of WOODCLEAN.</p> <p>Allow surface to dry completely before applying top coats.</p>		

Coat Type:	1st Coat	Datasheet:	AU_DW02187 Feast Watson Matt Look Deck
Application Methods:	  Brush Pad		
	Theoretical Spread Rate *	Min	Max
	Recoat Time **	4 hours	12
Coating Application Details:	<p>MATT LOOK DECK does NOT require thinning.</p> <p>For a slip resistant surface on stairs, ramps and wet areas, add Intergrain UltraGrip™* additive into each coat of MATT LOOK DECK.</p> <p>Allow the timber to dry completely before applying MATT LOOK DECK. MATT LOOK DECK should be stirred thoroughly before and during application with a flat blade stirrer taking care not to introduce bubbles. If the job requires more than one can of oil, mix both cans together in one large container prior to commencing. Do NOT apply with a roller. Apply one coat of MATT LOOK DECK using a quality synthetic or pure bristle brush or lambswool applicator. Work along 3-4 planks at a time, in the direction of the grain. Ensure edges and end grain are fully coated. Maintain a wet edge at all times. Do not over brush or apply thinly, as insufficient film thickness will compromise performance and durability. Allow to dry for 4 hours. Apply a second coat as above. A third coat of MATT LOOK DECK may be required in extreme conditions such as full sun exposure, around pools and in humid areas, and may be required on porous timbers. Allow to dry for 12 hours before light foot traffic.</p> <p>Do NOT apply in temperatures under 10°C or above 35°C or when rain or heavy dew is expected within the coating dry time.</p> <p>MAINTENANCE Regularly monitor coated timber for signs of colour loss, dryness and weathering. Recoat the timber when it begins to show signs of dryness to help maintain its natural beauty and protection. When required, clean the surface using WOODCLEAN, allow the surface to dry and recoat with one coat of MATT LOOK DECK.</p> <p>SLIP RESISTANT FINISH A slip resistant finish can be obtained by applying the following system: - 2 coats of Feast Watson Matt Look Deck, with 5% Intergrain UltraGrip added to each coat.</p> <p>Intergrain UltraGrip must be added at a rate of 5%. That is: - 200g of UltraGrip for 4L of coating - 500g of UltraGrip for 10L of coating</p> <p>When UltraGrip is added, the sheen or gloss level of the resultant coating will be lower than normal. When using UltraGrip, do not sand between coats. To avoid spillage, it may be necessary to remove 500ml of the timber coating from the can before adding UltraGrip. While stirring, add UltraGrip slowly to avoid generating dust. Stir in UltraGrip thoroughly with a flat blade stirrer. Add removed timber coating back to the can as space becomes available. Stir thoroughly. Stir regularly during use.</p> <p>SLIP RESISTANCE RATING When the system described above is applied, the resultant finish achieves the following slip rating:</p> <p>Tested to AS4586-2013 Slip resistance classification of new pedestrian surface materials. WET Pendulum = Class P4</p> <p>MAINTAINING A SLIP RESISTANT FINISH In order to maintain a slip resistant finish, decking or walkways must be recoated as the slip resistance decreases due to wear. When recoating is required - Clean the surface with Feast Watson Woodclean, following label instructions. - Allow the surface to fully dry. - Apply 1 coat of Feast Watson Matt Look Deck with 5% Intergrain UltraGrip added. Follow label instructions. - Further coats of Feast Watson Matt Look Deck with 5% Intergrain UltraGrip added can be applied if required for additional weather durability.</p>		

Coat Type:	2nd Coat	Datasheet:	AU_DW02187 Feast Watson Matt Look Deck
Application Methods:	  Brush Pad		
	Theoretical Spread Rate *	Min	Max
	Recoat Time **	4 hours	12
Coating Application Details:	<p>MATT LOOK DECK does NOT require thinning.</p> <p>For a slip resistant surface on stairs, ramps and wet areas, add Intergrain UltraGrip™* additive into each coat of MATT LOOK DECK.</p> <p>Allow the timber to dry completely before applying MATT LOOK DECK. MATT LOOK DECK should be stirred thoroughly before and during application with a flat blade stirrer taking care not to introduce bubbles. If the job requires more than one can of oil, mix both cans together in one large container prior to commencing. Do NOT apply with a roller. Apply one coat of MATT LOOK DECK using a quality synthetic or pure bristle brush or lambswool applicator. Work along 3-4 planks at a time, in the direction of the grain. Ensure edges and end grain are fully coated. Maintain a wet edge at all times. Do not over brush or apply thinly, as insufficient film thickness will compromise performance and durability. Allow to dry for 4 hours. Apply a second coat as above. A third coat of MATT LOOK DECK may be required in extreme conditions such as full sun exposure, around pools and in humid areas, and may be required on porous timbers. Allow to dry for 12 hours before light foot traffic.</p> <p>Do NOT apply in temperatures under 10°C or above 35°C or when rain or heavy dew is expected within the coating dry time.</p> <p>MAINTENANCE Regularly monitor coated timber for signs of colour loss, dryness and weathering. Recoat the timber when it begins to show signs of dryness to help maintain its natural beauty and protection. When required, clean the surface using WOODCLEAN, allow the surface to dry and recoat with one coat of MATT LOOK DECK.</p> <p>SLIP RESISTANT FINISH A slip resistant finish can be obtained by applying the following system: - 2 coats of Feast Watson Matt Look Deck, with 5% Intergrain UltraGrip added to each coat.</p> <p>Intergrain UltraGrip must be added at a rate of 5%. That is: - 200g of UltraGrip for 4L of coating - 500g of UltraGrip for 10L of coating</p> <p>When UltraGrip is added, the sheen or gloss level of the resultant coating will be lower than normal. When using UltraGrip, do not sand between coats. To avoid spillage, it may be necessary to remove 500ml of the timber coating from the can before adding UltraGrip. While stirring, add UltraGrip slowly to avoid generating dust. Stir in UltraGrip thoroughly with a flat blade stirrer. Add removed timber coating back to the can as space becomes available. Stir thoroughly. Stir regularly during use.</p> <p>SLIP RESISTANCE RATING When the system described above is applied, the resultant finish achieves the following slip rating:</p> <p>Tested to AS4586-2013 Slip resistance classification of new pedestrian surface materials. WET Pendulum = Class P4</p> <p>MAINTAINING A SLIP RESISTANT FINISH In order to maintain a slip resistant finish, decking or walkways must be recoated as the slip resistance decreases due to wear. When recoating is required - Clean the surface with Feast Watson Woodclean, following label instructions. - Allow the surface to fully dry. - Apply 1 coat of Feast Watson Matt Look Deck with 5% Intergrain UltraGrip added. Follow label instructions. - Further coats of Feast Watson Matt Look Deck with 5% Intergrain UltraGrip added can be applied if required for additional weather durability.</p>		

Coat Type:	Optional	Datasheet:	AU_DW02187 Feast Watson Matt Look Deck
Application Methods:	  Brush Pad		
	Theoretical Spread Rate *	Min	Max
	Recoat Time **	4 hours	12
Coating Application Details:	<p>MATT LOOK DECK does NOT require thinning.</p> <p>For a slip resistant surface on stairs, ramps and wet areas, add Intergrain UltraGrip™* additive into each coat of MATT LOOK DECK.</p> <p>Allow the timber to dry completely before applying MATT LOOK DECK. MATT LOOK DECK should be stirred thoroughly before and during application with a flat blade stirrer taking care not to introduce bubbles. If the job requires more than one can of oil, mix both cans together in one large container prior to commencing. Do NOT apply with a roller. Apply one coat of MATT LOOK DECK using a quality synthetic or pure bristle brush or lambswool applicator. Work along 3-4 planks at a time, in the direction of the grain. Ensure edges and end grain are fully coated. Maintain a wet edge at all times. Do not over brush or apply thinly, as insufficient film thickness will compromise performance and durability. Allow to dry for 4 hours. Apply a second coat as above. A third coat of MATT LOOK DECK may be required in extreme conditions such as full sun exposure, around pools and in humid areas, and may be required on porous timbers. Allow to dry for 12 hours before light foot traffic.</p> <p>Do NOT apply in temperatures under 10°C or above 35°C or when rain or heavy dew is expected within the coating dry time.</p> <p>MAINTENANCE Regularly monitor coated timber for signs of colour loss, dryness and weathering. Recoat the timber when it begins to show signs of dryness to help maintain its natural beauty and protection. When required, clean the surface using WOODCLEAN, allow the surface to dry and recoat with one coat of MATT LOOK DECK.</p> <p>SLIP RESISTANT FINISH A slip resistant finish can be obtained by applying the following system: - 2 coats of Feast Watson Matt Look Deck, with 5% Intergrain UltraGrip added to each coat.</p> <p>Intergrain UltraGrip must be added at a rate of 5%. That is: - 200g of UltraGrip for 4L of coating - 500g of UltraGrip for 10L of coating</p> <p>When UltraGrip is added, the sheen or gloss level of the resultant coating will be lower than normal. When using UltraGrip, do not sand between coats. To avoid spillage, it may be necessary to remove 500ml of the timber coating from the can before adding UltraGrip. While stirring, add UltraGrip slowly to avoid generating dust. Stir in UltraGrip thoroughly with a flat blade stirrer. Add removed timber coating back to the can as space becomes available. Stir thoroughly. Stir regularly during use.</p> <p>SLIP RESISTANCE RATING When the system described above is applied, the resultant finish achieves the following slip rating: Tested to AS4586-2013 Slip resistance classification of new pedestrian surface materials. WET Pendulum = Class P4</p> <p>MAINTAINING A SLIP RESISTANT FINISH In order to maintain a slip resistant finish, decking or walkways must be recoated as the slip resistance decreases due to wear. When recoating is required - Clean the surface with Feast Watson Woodclean, following label instructions. - Allow the surface to fully dry. - Apply 1 coat of Feast Watson Matt Look Deck with 5% Intergrain UltraGrip added. Follow label instructions. - Further coats of Feast Watson Matt Look Deck with 5% Intergrain UltraGrip added can be applied if required for additional weather durability.</p>		
Coating System Notes:	<p>* Practical Spreading Rate will vary from the quoted Theoretical Spreading Rate due to factors such as method and condition of application and surface roughness. ** Recoat times are quotes for 25°C and 50% relative humidity, these may vary under different conditions.</p>		

Disclaimer

Dulux, Selleys and Other marks followed by ® are registered trademarks. Marks followed by the symbol of ™ are trademarks.

The data provided within the Duspec system is correct at the time of publication, however it is the responsibility of those using this information to check that it is current prior to specifying or using any of these coating/product systems.

DISCLAIMER: Any advice, recommendation, information, assistance or service provided by any of the divisions of DuluxGroup (Australia) Pty Ltd or its related entities (collectively, DuluxGroup) in relation to goods manufactured by it or their use and application is given in good faith and is believed by DuluxGroup to be appropriate and reliable. However, any advice, recommendation, information, assistance or service provided by DuluxGroup is provided without liability or responsibility PROVIDED THAT the foregoing shall not exclude, limit, restrict or modify the right entitlements and remedies conferred upon any person or the liabilities imposed upon DuluxGroup by any condition or warranty implied by Commonwealth, State or Territory Act or ordinance void or prohibiting such exclusion limitation or modification. Coating/product systems can be expected to perform as indicated on the Duspec Spec Sheet so long as applications and application procedures of the individual products are followed as recommended on the appropriate Product data Sheet. "DuluxGroup" "Dulux" "Selleys" "Berger" "Berger Gold Label" "Hadrian" "Walpamur" "Levene" "Acratex" and Other marks followed by ® are registered trademarks of DuluxGroup (Australia) Pty Ltd ABN 67 000 049 427. Marks followed by the symbol ™ are trademarks.

Please note that this document is only valid for 60 days from the date of issue.

DuluxGroup (Australia) Pty Ltd 1956 Dandenong Road, Clayton, Victoria 3168 AU ABN 67 000 049 427