












Intergrain Ultraclear Interior Satin / over Feast Watson Proof Tint on New Timber [Interior] AU_SW14445

Description
<p>Intergrain UltraClear Interior is a tough, clear, water based finish for use on interior timber. Incorporating UV absorbers, UltraClear Interior provides greater protection against the colour change of timbers by shielding against the UV rays. UltraClear Interior resists abrasion, water and most household chemicals, is low odour and unlike oil based coatings will not yellow. Easy to apply and fast drying UltraClear Interior allows for several coats to be applied in one day. Available in gloss and satin, UltraClear Interior may be tinted to a selection of colours to create a 'one step' stain and varnish.</p> <p>Note: UltraClear Interior is not suitable for coating areas subject to foot traffic.</p> <p>#ENVIRONMENTALLY RESPONSIBLE:</p> <p>Being water based, UltraClear Interior emits significantly less VOC's (volatile organic compounds) into the atmosphere than traditional oil based interior clear finishes. This makes UltraClear Interior safer to use, and much gentler on the environment.</p> <p>Feast Watson PROOFTINT is a unique concentrated spirit based dye stain that allows the full clarity of the timber grain to show through after staining. PROOFTINT is suitable for all interior timber, including furniture, doors, architraves and floors, and is suitable for use on all timber varieties including pine. PROOFTINT is a versatile stain that can be applied directly to the surface or diluted in Feast Watson PROOFTINT COLOUR REDUCER or Feast Watson TIMBER PRIMER. Additionally, PROOFTINT can be added to Feast Watson CLEAR VARNISH to create a one-step stain and varnish, or added to Feast Watson LIMING SOLUTION to achieve a range of soft pastel shades. PROOFTINT colours can be mixed together to create your own custom shade or to achieve colour matches for your timber.</p>

Substrate And Substrate Preparation	
<p>Substrate Notes:</p>	<p>SUBSTRATE DESCRIPTION</p> <p>NEW TIMBER New timber items should be delivered in a clean dry condition, just prior to installation. The timber should be inspected for physical defects, such as splinters, cracks, woolly grain, machine marks, and knot holes and also for other defects such as sap and tannin stains, and resin exudation from knots. Examine surfaces for wax or preservatives. Moisture content should be close to equilibrium, usually 10-17% for satisfactory staining or coating. Timber should be stored out of the weather before painting. Timber left exposed to the weather for as little as one month prior to painting will suffer from reduced paint adhesion and durability.</p> <p>AGED TIMBER Old timber surfaces should be inspected for dry rot, mould or fungus, excessive water content, grey and weathered timber, grain cracking, resins, stains, old unsound paint, dirt and any surface contamination. These defects should be rectified prior to painting.</p> <p>TANNIN RICH TIMBER Tannins are water-soluble compounds present in some timbers such as meranti, merbau, kwila, western red cedar and tallowwood. These tannins are leached out by water or moisture and can cause staining of surrounding areas. They are seen as dark coloured stains either under or within a coating. Tannin staining is most obvious in light coloured coatings, such as whites. Darker and wood-toned colours hide the tannin stains best. When using light colours on tannin rich timbers, an appropriate primer should be used to seal the tannins in the wood.</p> <p>MANUFACTURED HARDBOARD These products are manufactured as smooth sheets consisting of wood fibres bound with either natural lignin or a small percentage of phenolic resin. Hardboard is widely used as interior panelling but is vulnerable to moisture and therefore not suitable for exterior exposure or in high condensation conditions. Repairing damaged hardboard is not generally practical and it is advisable to completely replace any damaged sections. These products are manufactured from timber fibre bound with thermosetting phenol formaldehyde resin. They contain wax which may inhibit the drying of solvent based alkyd enamels and tannins which may bleed through water based coatings. As manufactured the smooth surfaces provide an ideal surface for finishing but machined edges are more porous and may show fibre raising when primed.</p>
<p>Substrate Preparation Notes:</p>	<p>ASSESS SUITABILITY Ensure the wood is thoroughly clean and dry before commencing. If there is any doubt, measure moisture content which must be between 10-17% before staining or finishing can commence.</p> <p>REMOVE SURFACE CONTAMINANTS Examine the surface for the presence of sap, grease, oil, wax, tannin, building marks, or other contaminants. Scrape off and remove residual contaminants by solvent cleaning. Use scraper to remove dirt and mortar splashes. Any greyed wood fibres on aged timbers need to be removed by sanding and / or suitable chemical wood cleaner. CLEAN Clean to remove all dirt, dust and all other surface contaminants by using a suitable cleaning agent and rinse off with clean water. Treat mould with a suitable mould treatment.</p> <p>REPAIR SURFACE IMPERFECTIONS Fill nail holes, cracks and other defects with a suitable wood filler and allow to dry thoroughly.</p> <p>SANDING Sand dressed timber with fine sandpaper in direction of the grain and along the full length of the board. Round off all sharp edges to a minimum of 2 mm radius in order to achieve an even film build and uniform paint coverage.</p>

Coating System Summary	
1st Coat:	AUDW0729: Feast Watson Proofint
2nd Coat:	AUDW0762: Intergrain Ultraclear Interior Satin
3rd Coat:	AUDW0762: Intergrain Ultraclear Interior Satin
Optional:	AUDW0762: Intergrain Ultraclear Interior Satin
Please refer to the coating system details below	

Coating System			
Coat Type:	1st Coat	Datasheet:	AUDW0729 Feast Watson Proofint
Application Methods:	  Brush Other Rag		
Theoretical Spread Rate *		Min	Max
		10	20
Coating Application Details:	<p>Test colour on an off-cut or inconspicuous area prior to staining the whole job to ensure satisfaction with colour choice. Colour can be varied by mixing PROOFTINT colours and adding PROOFTINT COLOUR REDUCER. Note: The dwell time before wiping excess, and the finishing clear coat will impact the final colour.</p> <p>For Small Areas For small and detailed areas, apply PROOFTINT mix directly to the surface in the direction of the grain, by either brush or rag. Wipe off after 2-5 minutes depending on the depth of colour required. Allow to dry, then seal with CLEAR VARNISH as per the label instructions.</p> <p>For Large Areas For large areas including floors, dilute PROOFTINT in PROOFTINT COLOUR REDUCER which will give more working time to distribute the stain evenly. Apply with a rag, brush or Feast Watson FLOOR FINISH APPLICATOR in the direction of the grain. Wipe off excess after a period of time determined by the desired colour intensity. Allow to dry, then seal with FLOORSEAL OIL, FLOORCLEAR or FLOORPROOF PRO as per the label instructions.</p> <p>Stain & Varnish Method Add up to 10% PROOFTINT to CLEAR VARNISH or LIMING SOLUTION and apply as per the label instructions.</p>		
Coat Type:	2nd Coat	Datasheet:	AUDW0762 Intergrain Ultraclear Interior Satin
Application Methods:	   Air Spray Airless Spray Brush		
Theoretical Spread Rate *		Min	Max
Recoat Time **		3 hours	14
Coating Application Details:	<p>Do not apply by roller. Stir thoroughly before and during use with a flat blade stirrer. Do not shake or thin. If project requires more than one can of tinted UltraClear Interior, mix all cans together in one large container to ensure colour uniformity. Apply a minimum of two generous coats of UltraClear Interior with a quality synthetic or pure bristle brush or by spray (air assisted or airless). Take care to apply sufficient product to edges and end grain. Maintain a wet edge to avoid lap marks and an uneven finish. When applying by brush, lay off in the direction of the grain. To aid application, soak the brush in water and remove surplus before loading with UltraClear Interior. Do not overwork as this can result in poor appearance. When spraying ensure adequate film build is applied to achieve maximum durability. It is normal for UltraClear Interior to have a milky appearance when first applied, this disappears on drying. Allow a minimum of three hours drying between coats. Sand lightly with fine grit sandpaper to remove any raised grain. If coating large surfaces in warm conditions, wash the brush out at regular intervals to allow smooth application. If using tinted UltraClear Interior, the colour will become deeper with each application. If desired colour is achieved after one coat, apply untinted UltraClear Interior to complete the required number of coats.</p> <p>MAINTENANCE Clean using water and a non-abrasive household detergent. To ensure minimum preparation when recoating, surfaces should be recoated before UltraClear Interior has worn away to expose bare timber. Clean to remove any waxes or polishes. When dry, sand to a uniform surface and wipe away dust. Apply one to two coats following application instructions. Where UltraClear Interior has worn away to expose bare timber it must be thoroughly removed and the surface prepared as per instructions for new timber. A combination of Liquid 8 Timber Stripper* and sanding is recommended.</p>		

Coat Type:	3rd Coat	Datasheet:	AUDW0762 Intergrain Ultraclear Interior Satin
Application Methods:	  	Air Spray Airless Spray Brush	
Theoretical Spread Rate *		Min	Max
Recoat Time **		3 hours	14
Coating Application Details:	<p>Do not apply by roller.</p> <p>Stir thoroughly before and during use with a flat blade stirrer. Do not shake or thin. If project requires more than one can of tinted UltraClear Interior, mix all cans together in one large container to ensure colour uniformity.</p> <p>Apply a minimum of two generous coats of UltraClear Interior with a quality synthetic or pure bristle brush or by spray (air assisted or airless). Take care to apply sufficient product to edges and end grain. Maintain a wet edge to avoid lap marks and an uneven finish. When applying by brush, lay off in the direction of the grain. To aid application, soak the brush in water and remove surplus before loading with UltraClear Interior.</p> <p>Do not overwork as this can result in poor appearance. When spraying ensure adequate film build is applied to achieve maximum durability. It is normal for UltraClear Interior to have a milky appearance when first applied, this disappears on drying.</p> <p>Allow a minimum of three hours drying between coats. Sand lightly with fine grit sandpaper to remove any raised grain.</p> <p>If coating large surfaces in warm conditions, wash the brush out at regular intervals to allow smooth application.</p> <p>If using tinted UltraClear Interior, the colour will become deeper with each application. If desired colour is achieved after one coat, apply untinted UltraClear Interior to complete the required number of coats.</p> <p>MAINTENANCE</p> <p>Clean using water and a non-abrasive household detergent.</p> <p>To ensure minimum preparation when recoating, surfaces should be recoated before UltraClear Interior has worn away to expose bare timber. Clean to remove any waxes or polishes. When dry, sand to a uniform surface and wipe away dust. Apply one to two coats following application instructions.</p> <p>Where UltraClear Interior has worn away to expose bare timber it must be thoroughly removed and the surface prepared as per instructions for new timber. A combination of Liquid 8 Timber Stripper* and sanding is recommended.</p>		
Coat Type:	Optional	Datasheet:	AUDW0762 Intergrain Ultraclear Interior Satin
Application Methods:	  	Air Spray Airless Spray Brush	
Theoretical Spread Rate *		Min	Max
Recoat Time **		3 hours	14
Coating Application Details:	<p>Do not apply by roller.</p> <p>Stir thoroughly before and during use with a flat blade stirrer. Do not shake or thin. If project requires more than one can of tinted UltraClear Interior, mix all cans together in one large container to ensure colour uniformity.</p> <p>Apply a minimum of two generous coats of UltraClear Interior with a quality synthetic or pure bristle brush or by spray (air assisted or airless). Take care to apply sufficient product to edges and end grain. Maintain a wet edge to avoid lap marks and an uneven finish. When applying by brush, lay off in the direction of the grain. To aid application, soak the brush in water and remove surplus before loading with UltraClear Interior.</p> <p>Do not overwork as this can result in poor appearance. When spraying ensure adequate film build is applied to achieve maximum durability. It is normal for UltraClear Interior to have a milky appearance when first applied, this disappears on drying.</p> <p>Allow a minimum of three hours drying between coats. Sand lightly with fine grit sandpaper to remove any raised grain.</p> <p>If coating large surfaces in warm conditions, wash the brush out at regular intervals to allow smooth application.</p> <p>If using tinted UltraClear Interior, the colour will become deeper with each application. If desired colour is achieved after one coat, apply untinted UltraClear Interior to complete the required number of coats.</p> <p>MAINTENANCE</p> <p>Clean using water and a non-abrasive household detergent.</p> <p>To ensure minimum preparation when recoating, surfaces should be recoated before UltraClear Interior has worn away to expose bare timber. Clean to remove any waxes or polishes. When dry, sand to a uniform surface and wipe away dust. Apply one to two coats following application instructions.</p> <p>Where UltraClear Interior has worn away to expose bare timber it must be thoroughly removed and the surface prepared as per instructions for new timber. A combination of Liquid 8 Timber Stripper* and sanding is recommended.</p>		
Coating System Notes:	<p>* Practical Spreading Rate will vary from the quoted Theoretical Spreading Rate due to factors such as method and condition of application and surface roughness.</p> <p>** Recoat times are quotes for 25°C and 50% relative humidity, these may vary under different conditions.</p>		

Comments
<ul style="list-style-type: none"> Do not apply paint if the temperature is below 10°C or likely to fall below 10°C during the drying period.

Disclaimer

Dulux, Selleys and Other marks followed by ® are registered trademarks. Marks followed by the symbol of ™ are trademarks.

The data provided within the Duspec system is correct at the time of publication, however it is the responsibility of those using this information to check that it is current prior to specifying or using any of these coating/product systems.

DISCLAIMER: Any advice, recommendation, information, assistance or service provided by any of the divisions of DuluxGroup (Australia) Pty Ltd or its related entities (collectively, DuluxGroup) in relation to goods manufactured by it or their use and application is given in good faith and is believed by DuluxGroup to be appropriate and reliable. However, any advice, recommendation, information, assistance or service provided by DuluxGroup is provided without liability or responsibility PROVIDED THAT the foregoing shall not exclude, limit, restrict or modify the right entitlements and remedies conferred upon any person or the liabilities imposed upon DuluxGroup by any condition or warranty implied by Commonwealth, State or Territory Act or ordinance void or prohibiting such exclusion limitation or modification. Coating/product systems can be expected to perform as indicated on the Duspec Spec Sheet so long as applications and application procedures of the individual products are followed as recommended on the appropriate Product data Sheet. "DuluxGroup" "Dulux" "Selleys" "Berger" "Berger Gold Label" "Hadrian" "Walpamur" "Levene" "Acratex" and Other marks followed by ® are registered trademarks of DuluxGroup (Australia) Pty Ltd ABN 67 000 049 427. Marks followed by the symbol ™ are trademarks.

Please note that this document is only valid for 60 days from the date of issue.

DuluxGroup (Australia) Pty Ltd 1956 Dandenong Road, Clayton, Victoria 3168 AU ABN 67 000 049 427